

VOL. I (B)

ACRONYMS AND DEFINITIONS

VOL. I (B)- ACRONYMS AND DEFINITIONS

3MS	Materials Maintenance Management System. WMATA database for tracking maintenance and material stock.
A-E	Architectural and Engineering firm or contractor
BOP	Book of Plans. A set of drawings (11x17) based on our Typical Drawing Standards that depict all equipment and wiring within the TCR and wayside.
CSI	Construction Specification Institute. 50 Divisions CSI is a widely used standard for organizing specifications and other written information for commercial and institutional building projects in the United States and Canada.
DA	Design Assumptions and Analysis
DBE	Disadvantaged Business Enterprise
IDIQ	Indefinite Delivery Indefinite Quantity Contract. A type of contract that provides for an indefinite quantity of supplies or services during a fixed period of time.
LB-LC	Line Battery-Line Common: Power Supplies that provide non-grounded DC bus voltage for operating the 28 VDC ATC vital logic circuits which extend outside the Train Control Rooms.
MTBF	Mean Time Between Failures
MTTR	Mean Time To Restore (after failure)
PROCORE	Web based program used by WMATA for tracking projects and submittals
TCR	Train Control Room. The room where most train control electronics for the area (including the power supplies to be replaced) are housed. Typically there is one TCR per station.
WHB	Switch Machine Power Supply. WHB = positive bus WHC = common bus